

# SERVICE INSTRUCTIONS

www.keatingofchicago.com

**KEATING**  
OF CHICAGO, INC. ®



Part # 058545

1-800-KEATING

## REPLACING PART #032242 (Lighted Rocker Switch) WITH PART #058328 (Non-lighted Rocker Switch)

Please select the wiring diagram for your fryer and wire the new switch as shown

### Model IFM





#### WIRE COLOR CODES

BL - BLACK  
BU - BLUE  
RD - RED  
YL - YELLOW  
WH - WHITE

#### TERMINAL CODES

H - HOT  
N - NEUTRAL

### Model BB




#### WIRE COLOR CODES

BL - BLACK  
BU - BLUE  
RD - RED  
YL - YELLOW  
WH - WHITE


#### TERMINAL CODES

H - HOT  
N - NEUTRAL

## Model TS



## Model CPU



If the wiring version for your switch is not shown, please call 1-800- KEATING.  
Have you model and serial numbers available.